

# **IRONWORKERS CANADA - PRODUCT CATALOG**

# IRONWORKERS

# 60 TON



#### SPECIFICATIONS

60
1 diam. In 3/4 mild steel
36-9/16
8-7/8
1-1/4
3/8 x 14 1/2 x 12 3/4 x 4
34-1/2
7/8 diam.
7/8
3 x 3 x 1/2 4 x 4 x 3/8
39-7/8
2-1/2 x 4 x 5/16
39-1/2
5 HP
23
3-1/2
2500
7
36-1/8 x 46-1/8 x 56-1/8
45 x 51 x 63
2,550

#### FLEXIBILITY

- Four workstations:
  - **Standard (4)** Punch, Flat Bar Shear, Angle Shear & Coper Notcher



- 9 interchangeable Attachments available to tailor the Ironworker to your needs
- 17 optional Accessories available to increase precision and efficiency

#### PRODUCTIVITY

- Compact machine that allows for fast and easy transitions between fabrication operations: punch, shear, notch, bend and cope all in one machine.
- Optimized workstation heights for improved efficiency
- Electric foot pedal with integrated jog control
- Adjustable electric stoke control

#### SAFETY

- Bright LED lights increase visibility
- ANSI B11.5-1988(02) Compliant Guarding
- ETL Certified Controls
- Integrated Lock-out/Tag-out system with E-Stop for added safety

#### PERFORMANCE

- Durable, heavy-duty, Made In USA steel construction
- Vertical movement produces even pressure resulting in precise punching and shearing with minimal distortion that results in extended tooling life
- Punches are easily changeable, long-lasting and available from 1/8" to 4" diameters along with square, oblong, hex, metric, and custom shapes
- Flat Bar Shear blades are made of precision machined, high-quality tool steel with 4 cutting edges for extended life
- Angle Shear blades have 2 corner radii for both thin and thick material and are made of precision tool steel with 2 cutting edges for extended life

STOCK #	PRODUCT DESCRIPTION
IW60-1P230	60 Ton Ironworker 1 Phase, 230 Volt
IW60-3P208	60 Ton Ironworker 3 Phase, 208 Volt
IW60-3P230	60 Ton Ironworker 3 Phase, 230 Volt
IW60-3P380	60 Ton Ironworker Int'l - 3 Phase, 380 Volt, 50 Hz
IW60-3P460	60 Ton Ironworker 3 Phase, 460 Volt
IW60-3P575	60 Ton Ironworker 3 Phase, 575 Volt

## IRONWORKERSCANADA.COM

# 60 TON WITH FOWER LINK



### THE EXCLUSIVE EDWARDS POWERLINK<sup>™</sup> SYSTEM TURNS YOUR 60 TON IRONWORKER INTO A POWER SOURCE FOR OUR EVER INCREASING LINE OF HYDRAULIC TOOLS.

- Simply PLUG IN & POWER UP any of our Hydraulic Tools and expand your fabrication capabilities
- Our factory installed PowerLink System includes quick connect couplings allowing easy transitions between Hydraulic Tools
- The Edwards Portable Power Unit is an additional power source with the PowerLink System

POVER LINK			
STOCK #	PRODUCT DESCRIPTION		
IW60-1P230-AC500	60 Ton Ironworker 1 Phase, 230 Volt with PowerLink		
IW60-3P208-AC500	60 Ton Ironworker 3 Phase, 208 Volt with PowerLink		
IW60-3P230-AC500	60 Ton Ironworker 3 Phase, 230 Volt with PowerLink		
IW60-3P380-AC500	60 Ton Ironworker Int'l - 3 Ph, 380 V, 50 Hz with PowerLink		
IW60-3P460-AC500	60 Ton Ironworker 3 Phase, 460 Volt with PowerLink		
IW60-3P575-AC500	60 Ton Ironworker 3 Phase, 575 Volt with PowerLink		



EDWARDS-MADE IN THE USA SINCE 1875

# **IRONWORKERS**

# **60 TON** ATTACHMENTS



#### OVERSIZE PUNCH ASSEMBLY

• Accommodates punch & die sets in various shapes and sizes from 1" up to 1-9/16" Replaces Standard Punch Assembly or can be used as a secondary Punch Workstation

AC1024\*



#### **241 PUNCH ASSEMBLY**

metal to steel beams

 Accommodates punch & die sets in various shapes and sizes from 1" up to 4" Punch large holes and slots in anything from heavy sheet



#### ANGLE NOTCHER

- Take precise 92° notch out of mild steel up to 3" x 3" x 1/4"
- Allows for an easy 90° to create a steel frame

AC0125-1\*



#### PIPE NOTCHER HOUSING • Make clean 90° saddle joint

- connections quickly and easily · Compatible with all Edwards Ironworkers
- Contact Edwards for custom dies to match your project
- Pipe Notcher Dies sold separately

AC0925\*



#### **TURRET PIPE NOTCHER**

- Make clean 90° saddle joint connections quickly and easily
- · Compatible with all Edwards Ironworkers
- Contact Edwards for custom dies to match your project
- Pipe Notcher Dies sold separately

AC0925T\*



#### **MULTI SHEAR**

- Designed to shear flat bar up to 1/4" x 6" and angle iron up to 2" x 2" x 1/4" Shears solid round bar 1/4",
- 3/8", 1/2", 3/4" and 13/16" square bar

AC1075\*



#### **ROD SHEAR** Shear solid round rod easily with the Rod Shear • Handles 1/4", 3/8", 1/2" 5/8". 3/4" and 1" solid round bar

AC1074\*



#### **BRAKE WITH 4-WAY DIE**

AC1055\*

- Choose from the sizes listed below to meet your specific needs
- Fabricate brackets, frames, pans and tanks with this Brake with 4-Way Die

Includes a standard punch that allows $1/16^{\circ}$ , $1/8^{\circ}$ , $3/16^{\circ}$ and $1/4^{\circ}$ material to be formed to a 90° angle		
7"	8"	
AC1033*	AC1034*	



### IRONWORKERSCANADA.COM

## IRONWORKERS

# 60 TON ACCESSORIES



#### GAUGING TABLE KIT 3/8" thick 12" x 16" table that

adds precision to your Punch Workstation Compatible with both Standard and Oversize Pedestal Die Tables

Adjustable fences and handles quickly and easily guide your material for perfect repeatable actions AC0900



## HEAVY DUTY GAUGING TABLE KIT

1" x 12" x 16" table adds speed and precision to your Punch Workstation Replaces Standard Pedestal Die Table Adjustable fences and handles

quickly and easily guide your material for perfect repeatable actions AC0903



## HEAVY DUTY GAUGING TABLE KIT For oversized punch assembly

- 1" x 12" x 16" table adds speed ion to your Workstation
- Replaces installed Die Table Adjustable fences and handles quickly and easily guide your material for perfect repeatable actions

AC0905



COPER NOTCHER Gauging Table Kit • Provides a larger 3/8" x 12-1/2" x 15-5/8" size table and two fences to better align vour material

AC0800



STRIPPER REDUCING PLATE Designed to minimize distortion on thinner gauge

materials when using 1/2 punches & dies set or smaller AC1914-3



AC1099



#### QUICK CHANGE PUNCH ASSEMBLY Accommodates punch and Increase your efficiency by saving time and money with the Quick Change Punch Assembly. Accepts both Standard and

Oversize Punch & Die Sets

AC1001



#### AUTO CUT - 48' Optimize your productivity on both the Flat Bar Shear and Angle Shear Workstations on your Edwards Ironworker The adjustable proximity sensor automatically cycles your Ironworker as you feed

in material AC1010



#### BACK GAUGE - 48"

Speed up production on repeatable cuts by providing an adjustable stop for the Flat Bar Shear and Angle Shear A positive stop attachment that is fitted to the back of the Ironworker ensures accurate shearing





### PRESS BRAKE BACK GAUGE

Speed up production on repeatable bends by providing an adjustable stop for the various size Brake Attachments

A positive stop attachment that is fitted to the back of the Ironworker ensures accurate bending PR135



## PUNCH & DIE STARTER SET

Includes 8 standard round punch & die sets selected to accommodate the most commonly used bolts Sized in 1/8" increments from 3/16" to 1-1/16" with 1/32 clearance See catalog page 68-71 for additional Punch & Die Sets





allows users to attach the light to any Ironworker surface and move as needed

AC1000



FABRICATOR'S PROTRACTOR Increase user accuracy on the Punch and Flat Bar Shear Workstations Designed to guide your workpiece and gauged at 15° increments through 180°

AC1017



#### 12" & 18" FENCES GUIDES

PD1000

Easily adjustable to align your material, these 12" or 18" fence quides make precise. repeatable operations simple

AC1910 12" Standard Handles AC1911 18" Standard Handles AC1912 12" Heavy Duty Handles AC1913 18" Heavy Duty Handles



PRODUCTIVITY PACK Includes 5 Accessories designed to increase your accuracy and production speed. Accessory light • 48" Auto Cut

 Fabricator's Protractor • 3/8" x 12" x 16" Punch Station table

Punch & Die Starter Kit AC2000

### EDWARDS-MADE IN THE USA SINCE 1875





# BUILD YOUR LEGEND"





IRONWORKERSCANADA.COM SALES@IRONWORKERSCANADA.COM TOLL FREE: 1-(833)399-5395